

# PB-10

## PANIC BUTTON

**PB-10** is a wired panic button used to trigger a panic alarm or call for help. The button can also be used to control various devices (e.g. automation or access control system devices).

- tamper protection against opening the enclosure and detaching it from its mounting surface
- compatible with any alarm control panels that supports NC type detectors

